

Meets Standards:
C22.2 no 113 and UL 1812



INSTALLATION, OPERATIONS & MAINTENANCE MANUAL

InspirAIR® FRESH ENERGY RECOVERY VENTILATORS



FOR MODELS:

EK120-HF, EK120-HFX, EK120-HR, E120-HRX

TO BE COMPLETED BY CONTRACTOR AFTER INSTALLATION

Installer: Leave this manual for the homeowner

Model

Installing Contractor

Telephone / Contact

Serial Number

Installation Date

REGISTER YOUR PRODUCT ONLINE AT ALDES-NA.COM

TABLE OF CONTENTS

I. INTRODUCTION 3

II. GENERAL ERV TERMINOLY AND FEATURES 3

Definitions 3

How Energy Recovery Ventilators Work 3

Ventilation with an ERV 4

III. PRECAUTIONS & GUIDELINES 4

Ducting Configurations 6

Locating the Air Exchanger 8

Ducting Materials 8

Connecting the Ducts 9

Vent Hood Locations 9

Locating the Exhaust Air Grilles or Registers 10

Locating the Supply Air Grilles or Diffusers 11

Humidity Control 11

IV. INSTALLATION 12

What's included 12

Mounting the Unit 12

Electrical Diagram 13

Configuration Options 14

Unit Wiring 15

Wiring to the Power Source 17

Installing the Digital Multi-Function Control (P/N 611242-FC) 18

Digital Multi-Function Control Operation Modes 20

Installing the 20/40/60 Minute Timer (P/N 611228) 20

Installing the Speed Controller (P/N 611229) 20

ZRT VentZone System 21

V. MEASURING & BALANCING AIRFLOW 22

Measure and Balance 22

Door-Port Balancing 23

Balancing Airflow and Adjusting Motor Speed 24

Sample Door-Port Balancing Example 25

VI. MAINTENANCE 26

General Maintenance 26

Replacement Filters 27

Technical Assistance 27

Trouble Shooting 28

VII. WARRANTY 30

What's Included 30

How to File a Warranty Claim 30

VIII. APPENDICE 31

Appendix A. List of items (sold separately) for the installation of your ERV 31

I. INTRODUCTION

Thank you for purchasing this ALDES ventilation product. To receive the full benefit of your investment, we recommend that you read and retain this operating manual for future reference.

II. GENERAL ERV TERMINOLOGY AND FEATURES


Definitions

(Energy Recovery Ventilator): A ventilation device consisting of two fans and a energy recovery module that allows the transfer of heat and humidity between the supply and exhaust air resulting in a balanced supply of fresh air, without mixing the two airstreams.

How Energy Recovery Ventilators Work

In the heating season, ALDES Energy Recovery Ventilators (ERV) draw in fresh air from outside. This air is distributed throughout the home by a dedicated-duct system or through the forced-air heating/air conditioning system. At the same time, vents located in moisture- and pollutant-producing rooms (e.g., kitchens, bathrooms, laundry rooms) exhaust an equal amount of stale, humid air to the outside. Sometimes air is drawn directly from the return air of a forced-air heating/air conditioning system.

As the two airstreams cross each other in the unit's core, the fresh air is tempered with heat recovered from the exhaust air. An ERV will also transfer moisture to the fresh air if this air is drier than the exhaust air, improving comfort in overly dry homes.



In the cooling season, the reverse situation occurs. Fresh outdoor air is cooled by the air-conditioned exhaust air. If the outgoing air is drier than the fresh air, the ERV will transfer moisture to the outgoing air. This process reduces the humidity load on the air conditioning system, which would otherwise result in the continuous introduction of humid summer air

NOTE: It is important to understand that an ERV is not a dehumidifier by itself, but it will assist the air conditioner by removing much of the latent heat (water vapor) from the fresh air entering the home.

Multi-Unit Residential ERV

Ventilation with an ERV

Today's modern homes require fresh outdoor air to maintain a healthy indoor air environment. The amount of ventilation you require in your home will depend upon:

- Number of occupants and their activity levels
- How your home was built
- Your personal preferences for fresh air

The ALDES ERV introduces fresh air to your home while recovering energy from the air it exhausts. Specifically, an ERV that is properly installed, operated and maintained will:

- Exhaust stale, contaminated air
- Recover the majority of the energy from the exhausted stale air
- Use the recovered energy to pre-heat or pre-cool outside air drawn into the house
- Distribute the fresh air throughout the house

During seasons when your windows and doors are closed (winter and summer if air conditioned), the ERV should be set to operate continuously on low speed with the option of going to high speed as the need arises. For example, if you are entertaining and many people are present, you should temporarily switch the unit to high speed.

You may wish to use an intermittent operational mode if your home is unoccupied for long periods.

III. PRECAUTIONS & GUIDELINES

WARNING indicates the potential of risk of personal injury or death if not observed.

CAUTION identifies an action that may damage the unit, its components, or related equipment.

RECOMMENDATIONS and **NOTES** suggest operational modes, installation of vent hoods, interior supply and exhaust duct layouts, use of advanced features of the equipment that may result in improved economy and comfort.

Installation and operation of these units must be in accordance with applicable local building and safety codes.

WARNING!

To avoid injury or damage to this unit, do not attempt to service any of the internal electrical or mechanical components. Your energy recovery ventilator should be installed and serviced by a qualified heating and electrical contractor.

CAUTION

Before installation, careful consideration must be given to how this system will operate if connected to any other piece of mechanical equipment that operates at a higher static, i.e., a forced-air furnace or air handler. After installation, the compatibility of the two pieces of equipment must be confirmed by measuring the airflows of the ERV using the balancing procedure found in this manual.

NEVER install a ventilator in a situation where its normal operation, lack of operation, or partial failure may result in the backdrafting or improper functioning of vented combustion equipment.

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSON(S) OBSERVE THE FOLLOWING:

1. Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer at the address or telephone number provided.
2. Before servicing or cleaning the unit, disconnect the power cord from the electrical outlet.
3. This unit is not designed to provide combustion and/or dilution air for fuel-burning appliances.
4. This unit is not designed to provide make-up air for other exhausting devices, such as range exhaust hoods, clothes dryers, or other exhaust fans.
5. When cutting or drilling into wall or ceiling structures, do not damage electrical wiring or other hidden utilities.
6. Do not use this unit with any speed controls, dehumidistats or timers other than those specifically indicated within this manual.
7. The unit must be equipped with a ground connection. The NEC terminal block provides a terminal for connecting the ground wire to the unit. The unit's ground wire must therefore be connected to the building's grounding system in accordance with the building code. Do not use extension cords.
8. Do not install exhaust grilles in a cooking area (see "**Locating the Exhaust Air Grilles or Registers**" on page 13). Do not connect directly to any appliances.
9. Do not use to exhaust hazardous or explosive materials and vapors.
10. When performing installation, servicing or cleaning the unit, it is recommended to wear safety glasses and gloves.
11. When local regulations comprise more restrictive installation or certification requirements, such requirements supersede those in these instructions.

CAUTION

1. This unit is intended for residential use only, conforming to the requirements of the International Residential, Building, and Mechanical Codes, NFPA 90B for the United States and the National Building Code of Canada.
2. Turn the unit off during construction to avoid clogging the filters and loading the blowers with construction dust.
3. Refer to the specification sheet for the specific model's dimensions, electrical requirements, drain connections, etc.
4. Ducting of stale air to the outdoors and fresh air from outdoors, must be terminated outdoors, not attics, crawl spaces, or attached garage.

Ducting Configurations

The interior ducting system's purpose is to remove stale air and circulate fresh air to all habitable rooms. It is the responsibility of the installer to ensure all ductwork is sized and installed as designed to ensure the system will perform as intended.


The amount of air (CFM) that an ERV will deliver is directly related to the total external static pressure (ESP) of the system. Static pressure is a measure of resistance imposed on the blower by a length of ductwork plus the number of fittings used in the ductwork.

The following pages outline 3 duct configurations, from most desirable to least desirable.

Note: These configurations are intended for typical residences. Applications such as greenhouses, atriums, swimming pools, saunas, etc., have unique ventilation requirements that should be addressed with an isolated ventilation system.

Note: The way your heat/energy-recovery ventilator is installed can make a significant difference to the electrical energy you use. To minimize the electricity use of the heat/energy-recovery ventilator, a stand-alone fully ducted installation is recommended. If you choose a simplified installation that operates your furnace air handler for room-to-room ventilation, an electrically efficient furnace that has an electronically commutated (EC) variable speed blower motor will minimize your electrical energy consumption and operating cost.

Fully Ducted System – Best Configuration




The **fully ducted system** has the highest ventilation effectiveness. It is especially suited for homes without forced-air systems used for both heating and cooling. Dedicated exhaust grilles draw stale air from service rooms. Dedicated supply registers provide fresh air to main living areas and bedrooms. Grilles should be located high on a wall or in the ceiling. Grilles that diffuse the air are recommended. Special care should be taken in locating grilles in the floor. Areas under baseboard heaters will help temper the air. See **“Locating the Exhaust Air Grilles or Registers”** page 13 and **“Locating the Air Grilles of Diffusers”** page 13 . Also refer to the installation instructions included with these products (sold separately).

This system is not connected to an Air-Handling Unit (AHU) or furnace. This system is normally balanced on high speed. If ALDES patented* Zone Register Terminals (ZRT®) are used for exhaust or supply registers, balancing must be done at normal operating speed.

Consult the ZRT brochure fore more details on installing and ERV in conjuction with a ZRT system. For constant air flow models (HRX and HFX) the use of the ZRT is not recommended.

Partially Ducted System – Configuration



In a **partially ducted configuration**, individual exhaust grilles in bathrooms, laundry rooms, and kitchens draw stale air. Each location with a stale air duct could also have a timer that will initiate high-speed ventilation. Fresh air is distributed by the Air-Handling Unit (AHU) of a forced-air heating or air conditioning system. The connection to the forced-air system is typically to the return ducting or plenum of the AHU. See section **“Interlocking the ERV to an Air-Handler/Furnace Blower”** on page 18.

While this configuration is common in commercial installations, it is not always recommended for residences due to the following:


1. In this case, the AHU must run continuously or be interlocked to operate with the ERV to avoid loss of balanced supply and exhaust airflows.
2. In multi-speed AHU's, balancing must be conducted on the most frequently used speed, but the ERV may not remain in balance at other speeds.

Multi-Unit Residential ERV

3. In warm, humid seasons, continuous operation of the AHU causes evaporation from the cooling coil, resulting in a loss of humidity control. Failure to operate the AHU with the ERV may also result in condensation in the supply plenum and ducting.
4. Continuous operation of the AHU may cause drafts in the winter.
5. Backdraft or motorized dampers may be built into the ERV to prevent entry of outdoor air during off cycles, but they should not be installed in the duct leading to the outside.

Due to these reasons, it may be preferable to avoid a direct duct connection to the return of the AHU and use an **indirect approach** instead.

Indirectly Ducted System – Configuration



1. Fresh air to inside

2. Exhaust air from inside

3. Fresh air from outside

4. Exhaust to outside

5. Separation must comply with local codes

Note: Port configurations are generic and do not represent specific models

In this configuration, dedicated exhaust grilles remove stale air from bathrooms, laundry rooms, and kitchens. Fresh air is supplied to a large-volume room, such as a great room, family room, high stairway, etc. The forced-air system will draw the fresh air into the return grilles of the AHU and distribute it throughout the house. The ERV and AHU may operate independently with no impact on airflow balance.

A thermostat with a ventilation feature is recommended to turn on the AHU periodically to assure proper supply air distribution apart from heating/cooling cycles. This type of timer avoids the energy cost of operating the blower fan in the AHU, and it also lessens the concerns about draft in winter and re-evaporation from the AC coil in the summer.

Locating the Air Exchanger

The device must be located in a place where the temperature is always above freezing. Choose a location for the device where the ducts will be short with minimal use of elbows. This ensures that the system functions optimally.

Ducting Materials

1. Where ducting passes through concealed spaces (walls, ceiling-floor assemblies), the duct should be in metal to offer less resistance to airflow and permit duct cleaning.

- Where the ducts remain permanently accessible, 5 to 10 feet of insulated flexible duct should be used between the ERV and all interior supply and exhaust registers to reduce fan noise passing the ducting to interior spaces.


Connecting the Ducts

For the air exchanger to run optimally, place the ducts so they are as straight as possible. Ducts should be kept short and have as few bends or elbows as possible to maximize airflow. Forty-five degree elbows are preferred to 90-degree elbows. Use “Y” tees rather than straight tees whenever possible.


All ducts going through unheated areas must be insulated. The ducts between the exterior vent hoods and the ERV must be insulated and covered with a vapor barrier. See the next section “**Vent Hood Locations**”.

Flexible duct is recommended to provide vibration isolation between the unit and duct system. Start by determining the required duct length to reach each respective collar, and cut as required. If rigid duct is used, avoid attaching with screws to the duct collars, as they may interfere with the damper operations at each duct collar.

The EK120 models are equipped with twist-in collars to simplify the process of connecting flexible duct to your ventilator. Remove each duct collar by twisting them out of the locking tabs. Connect the ducts to the removed collars using duct tape and flexible duct straps. Reinstall collars, with duct attached, to their respective labeled ports on the ERV by lining up locking tabs and twisting on in a clockwise direction.



**Note: for illustration purposes only. The device does not represent a specific model.*



Note: For fresh air intake, the plastic duct collar with anti-return flap must be installed so that the flap is horizontal. Use the picture on the left as a reference. The red line indicates the horizontal position of the flap.

Vent Hood Locations

(Manufacturer's recommendation only. Also consult Local Building Code Requirement.)

Wall hoods (sold separately) should be placed in easy access location for cleaning purposes.

Note: Please refer to Installation Instructions packaged with wall hoods.

Fresh Air (Intake) Wall hoods:


- Should be located upstream (if there are prevailing winds) from the exhaust wall hood
- At least 6 feet (2 metres) from the exhaust wall hood
- At least 6 feet (2 metres) from dryer vents and furnace exhaust (medium or high-efficiency furnaces)
- At least 6 feet (2 metres) from driveways, oil fill pipes, gas meters or garbage containers.
- At least 18 inches (457 mm) above the ground, or above the depth of expected snow accumulation.
- At least 3 feet (1 metre) from the corner of the building.
- Do not locate in a garage, attic, or crawl space.

Multi-Unit Residential ERV

Exhaust Air Wall hoods:

- At least 6 feet (2 metres) from the fresh air intake wall hood.
- At least 18 inches (457 mm) above the ground, or above the depth of expected snow accumulation.
- At least 3 feet (1 metre) from the corner of the building.
- Not near a gas meter, electric meter, or a walkway where fog or ice could create a hazard
- Do not locate in a garage, workshop, or other unheated space.

Dual Intake and exhaust hoods: Concentric-type or dual intake/exhaust hoods may be used where authorized.




Note: Local codes may allow less or require greater distances between exhaust and intake wall hoods.

Locating the Exhaust Air Grilles or Registers (in systems with dedicated exhaust ducting)

The exchanger has at least one exhaust air intake register. Exhaust air registers should be placed where the humidity level is high, such as bathrooms, laundry rooms, and kitchens. However, do not install in areas of extreme humidity such as steam showers, jacuzzi rooms, indoor pools and solariums. Kitchen exhaust grilles must never be connected to the range hood. Do not install an exhaust grille ducted to the ERV in a cooking area, defined by the area above or inside a 45-degree angle projected outwards from the cooking element closest to the exhaust grille. See figure below.

Normally, the exhaust air intake register would be located on the first floor between the bathroom and the kitchen, or in the basement near the bathroom. Avoid placing it in the same room as a combustion device, such as a fireplace or furnace. The vent should be installed high on the wall or in the ceiling. If installed on the wall, it should be placed at least 12 inches (30 cm) from the ceiling.



Adjustable grilles can be used to balance the flow rates. Field supplied balancing dampers can be external to the unit to balance the amount of stale air being exhausted. These grilles should not be adjusted after balancing the unit.

Locating the Supply Air Grilles or Diffusers

The fresh air diffusers should be installed in hallways, near the primary return for the forced air system, in bedrooms and/or in common living areas. Diffusers should be located a reasonable distance from the exhaust registers to promote circulation of the fresh air throughout the dwelling. The supply diffusers should be installed high on the wall or in the ceiling. If the diffuser is located in a common area, it is recommended to place it on the ceiling so that it can better mix with the air in the room before reaching occupants. This will improve comfort in cold weather. If diffusers are installed on the wall, place them at least 12 inches (30 cm) from the ceiling.

Adjustable grilles can be used to balance the flow rates. Field supplied balancing dampers can be external to the unit to balance the amount of fresh air being supplied relative to the other diffusers. These grilles should not be adjusted after balancing the unit.

Humidity Control

Tight, well-insulated space may have high indoor humidity levels during the heating season. High humidity will be apparent from visible condensation on windows. The amount of window condensation will increase as outdoor temperatures drop. On summer nights, the outside air is often cooler than the air inside your home.

Your ERV will reduce indoor humidity levels when outdoor air is drier than indoor air. This usually occurs during the heating season when outdoor temperatures are less than 50°F (10°C), as shown in the following table:

RECOMMENDED RELATIVE HUMIDITY TO PREVENT INDOOR CONDENSATION*	
OUTSIDE AIR TEMPERATURE	RELATIVE HUMIDITY
0°C to 10°C (32°F to 50°F)	45% - 50%
-6°C to 0°C (21°F to 32°F)	40% - 45%
-12°C to -6°C (10°F to 21°F)	35% - 40%
-18°C to -12°C (0°F to 10°F)	25% - 30%
-24°C to -18°C (-11°F to 0°F)	20% - 25%
Under -24°C (-11°F)	Under 20%

ASHRAE 62.2 standards recommend maintaining a relative humidity rate between 30% and 60%. The average person is comfortable between 30-50% relative humidity (RH).

ALDES offers several wall controls with a dehumidistat function. Please refer to the wall control user guide for detailed information.

IV. INSTALLATION

What’s Included

Verify that all parts have been included with the shipment. If any parts are missing, notify your distributor as soon as possible. **Note: Quantity of parts may vary depending on model of air exchanger (e.g., single or double drain)**

- Heat or Energy Recovery Ventilator
- User manual
- Parts Bag:
- Rails (2)
- Hooks (4)
- Middle plate (1)



Other items used for standard installation can be bought seperately. Contact your local distributor to order ALDES items. Refer to **Appendice A** to see the list of items.

Mounting the units

Mounting the units using a ceiling bracket


It is highly recommended to refer to the detailed installation instructions that are provided with the ceiling bracket kit.

Assemble the ceiling bracket, place the antivibration grommets and affix to the ceiling with appropriate fasteners. Next, attach the provided mounting brackets to the corners of the unit. Lift the end of the unit with the hooked brackets to the ceiling bracket and attach, then raise the other side of the unit until it snaps into place. Finally, use the two security screws to fix the unit to the ceiling bracket.




Note: to ensure quiet operation of the ENERGY STAR-certified ERV system, each product model must be installed using sound attenuation techniques appropriate to the installation.

Note on installation: To facilitate assembly of the unit, we recommend dividing the installation into two stages. The first is to install the unit without the core, which makes it easier to handle when attaching it to the rails. Once the unit has been installed on the rails in accordance with the “**Mounting the unit**” section of this manual, the second step is to install the recirculation core. To remove or install the core in the unit, assemble or disassemble the retaining bar (9209-112), as shown in the following illustration.



Electric Diagram



*Refer to the user guide for Aldes wall control installations

** Optional

*** Fuses 6,3A and 4A are replaceables

Options jumper block Programs jumper block

Multi-Unit Residential ERV

Configuration Options


In order to configure the different modes on your unit, you may need to move a jumper on the unit's printed circuit board. This can be done without any special tools following the directions below.

Suggestion: it is easiest to do this prior to installation, on a table with the unit on its back.

1. Disconnect the unit power cable to avoid electric shock or damaging the PCB.
2. Remove the unit's terminal block by firmly pulling it straight out.




3. Using a Phillips-head screwdriver, remove the three screws holding the electronic control box in place.




4. Once the screws have been removed, slide the electronic control box upwards to gain access to the PCB. Locate the jumper pins on the PCB. They are located just behind the motor speed controllers, at the front of the unit.
5. In order to configure the different modes available for the unit, you will need to move different jumpers in the Options jumper block. It is the block with jumper pins ranging from 1 through 7. Below are the configurations for the different options available.
6. 5a) Defrost modes
 - By default, the ERV is configured for **Normal Defrost**, with no jumpers on pin sets 5 and 6. Normal Defrost is optimized for most climate zones. The unit will automatically protect the core from frost build up by periodically switching to high speed recirculation or exhaust.

- For extremely cold climates, you can choose the **Extended Defrost** option which increases the time in which the unit stays in the defrost cycle. To activate the Extended Defrost option, position a jumper on the configuration port 6 and make sure it connects both pins in the row.




- The **Comfort Defrost** option prevents the ERV from switching from low to high speed and back during defrost cycles, so there will be no audible difference between exchange and defrost. To activate Comfort Defrost, position a jumper on the configuration port 5 and make sure it connects both pins in the row.



- Note that the Extended and Comfort Defrost settings can not be activated at the same time.** This means there should never be jumpers on both configuration ports 5 and 6.

5b) Slave mode

- In slave mode, an external device (e.g. air handler) or switch will determine when the ERV will operate.
- By default, the slave mode option is DISABLED.
- To activate slave mode, position a jumper on the configuration port 7 and make sure it connects both pins in the row.



- Once configuration is complete, replace the circuit board cover and the terminal block and proceed to wiring the unit to the controls.

Unit Wiring

A) Unit wiring to accessories

All units can be used with the following ALDES wall accessories:

611227: Electronic Humidistat with liquid crystal display

611229: Speed Control

Multi-Unit Residential ERV

611230: Mode Control


611242-FC: Digital Multifunction Wall Control

These can all be used on their own or with a timer (611228). To wire an accessory and/or a timer, connect the ERV as illustrated on the right.

With this wiring, the unit can be operated at the following settings:

- Off
- Low Speed Exchange
- High Speed Exchange
- Low Speed Recirculation
- High Speed Recirculation



Low and High speeds can be adjusted with **FlexControl** (refer to page 32).



B) Unit wiring for Slave Mode

In slave mode, an external device or switch will dictate when the unit will operate. This is the case for VentZone® Systems, use of third party thermostats with built in ERV controls, and use of external third party switches that are used to enable/disable the unit. Installations requiring a switch to enable or disable the unit via a wall switch will need to be placed into slave mode.

To enable low speed exchange, a connection must be made between terminals 1 and 3 (see illustration below). If this connection is open, the ERV will be put into standby mode. This connection can be made using any 24V switch or dry contact controller, such as a smart thermostat with integrated ventilator control or a programmable timer.



If low speed is insufficient and high speed is required to satisfy the ventilation rate, connect a jumper between terminals 3 and 4 in addition to the switched line between terminals 1 and 3 (see illustration below). This sets the ventilation speed to high.

C) Interlocking the ERV to an Air-Handler/Furnace Blower

Installations sharing ductwork with air-handling units or furnaces operate most effectively when those units are powered on to properly distribute the fresh air provided by the ventilator throughout the home. The ERV has the ability to interlock with external equipment, such as an air-handler or furnace blower, to activate or deactivate that equipment as necessary. The unit's terminal strip has two fan interlock options via terminals 6, 7, and 8 on the terminal block. Terminal 6 is NORMALLY CLOSED, and terminal 8 is NORMALLY OPEN. Terminal 7 is the ground for both 6 and 8.


For the ERV to operate only in conjunction with the Air-Handler/Furnace, do the following:

1. Connect the ERV as illustrated below. Refer to the AHU Owner's Manual/Wiring Diagram for instructions on connecting to the fan start relay.

Note: It is the same process as connecting the fan control on a thermostat.

2. Ensure the air-handler/furnace blower motor is operating whenever the ERV is ventilating.

Note: Consideration must be given to competing airflows when connecting the ERV in conjunction with an Air-Handler/Furnace Blower system.



Wiring to the Power Source

Once all the ducts are installed and the wires to the controllers are connected, connect the ERV to a 120V power source according to the model type:

Models without power cord (model numbers ending in -N):


WARNING: Cordless models must be wired to the building mains by a licensed electrician according to applicable electrical and building codes.

To wire the ERV:

1. Ensure that the circuit breaker is turned off during installation.
2. Locate the junction box on the ERV (see illustration below).
3. Remove the junction box cover with a Philips-head screwdriver. Retain the screws for later when replacing and securing the junction box cover (Step 7).

Multi-Unit Residential ERV

4. Insert the electrical conduit into the 7/8" (22.3 mm) hole in the junction box cover, and secure it with a clamp or washer and screw.
5. Pass the wire through the grommet.
6. Strip insulation 1/4" (6.4 mm) from the ends of the wires.
7. Connect the wires to the ERV terminal block
8. Replace the junction box cover over the box and secure it using the screws from Step 2.
9. Turn on the circuit breaker and confirm that the ERV powers up.



Installing the Digital Multifunction Control (P/N 611242-FC)

The Digital Multifunction Control (P/N 611242-FC) can be used with any type of ALDES Residential ERV. The controller should be installed in the place where excess humidity is most likely to be detected, for example near a bathroom, kitchen or in the basement. Ensure good air circulation around the controller. Do not place it behind a door, for example.




Please refer to the controller's documentation for detailed mounting and operating instructions. Note that the Automatic dehumidistat mode is intended to be used when the outdoor air has less moisture content than the indoor air. Turn off the Automatic mode when outdoor air is hot and humid.

CAUTION: Turn off power to avoid risk of malfunction.

To connect the Digital Multifunction Control to the ERV, follow these diagrams:

Note: *Installation of a user-accessible control with your product model will improve comfort and may significantly reduce the product model's energy use.*
















Set the ON/OFF switches to correspond to your ERV model, as listed in the following table:

<p>ON OFF</p> <p>With recirculation Models: EK120-HR, EK120-HRX</p>	<p>ON OFF</p> <p>Without recirculation Models: EK120-HF, EK120-HFX</p>
--	---

Connect each wire to the terminal board on the back of the controller face plate according to the connection chart shown on the mounting plate. Then connect the 4-conductor wire to the terminal board on the ERV according to the respective colors. The control operates at 24V.

The following table shows which operating modes are available for the different ON/OFF settings:

Digital Multi-Fuction Control Operation Modes

Mode	Speed	Description		
OFF	-	Unit stops completely. Remains idle regardless of the humidity level.	Yes	Yes
		Remains idle until the humidity goes above the setpoint.	Yes	Yes
		Continuously exchanges air with the outside at low speed.	Yes	Yes
		Continuously exchanges air with the outside at high speed.	Yes	Yes
		Recirculates interior air at low speed.	Yes	n/a
		Recirculates interior air at high speed.	Yes	n/a
		Exchanges air with the outside at low speed for 20 minutes. Then remains idle for 40 minutes.	Yes	Yes
		Continuously exchanges air with the outside at low speed for 20 minutes. Then recirculates interior air at low speed for 40 minutes.	Yes	n/a

Installing the 20/40/60 Minute Timer (P/N 611228)

This controller provides the ventilation unit with high-speed exterior exchange for the following durations:

- 20 minutes
- 40 minutes
- 60 minutes



A service box is recommended when installing the timer switch.

1. Run a 3-conductor low-voltage (24V) wire through the wall until it reaches the ERV.
2. Connect each wire to the timer switch according to its respective color.
3. Connect the 3 wires to the ERV's terminal block according to their colors. Wires must be sized for 24V.
4. Screw the backside of the control panel to the wall. Use the mounting screws to secure the top section into place.

Installing the Speed Control (P/N 611229)

This controller provides the ventilation unit with 4 modes of operation:


- Intermittent mode; successive cycles, low-speed 20-min exchange, 40-min stop mode or recirculation
- Low-speed exterior exchange mode
- High-speed exterior exchange mode
- Stop mode or recirculation (indicator lights are off)

1. Run a 4-conductor low-voltage (24V) electrical wire through the wall until it reaches the ERV.
2. Connect each wire to the control's terminal block according to its respective color.



3. Connect the 4 wires to the ERV's terminal block according to their colors.
4. Screw the backside of the control panel to the wall. Use the mounting screws to secure the top section into place.

ZRT VentZone® Systems *



Each ZRT is fitted with a self-balancing constant airflow regulator that allows controlled amounts of continuous IAQ ventilation when the damper is closed. The primary flow damper opens when called upon by any switch, timer, dehumidistat, or occupancy sensor. Once the damper is opened, the ZRT signals the ERV or ERV to boost speed and airflow from the open ZRT, making it ideal for residential bathroom ventilation.

****Note: for EK120-HR and EK120-HF models only. Models EK120-HRX and EK120-HFX have electronic automatic flow control.***

Getting Started

Before installing your ventilator, the unit must be configured to operate in SLAVE mode (see page 20). A maximum of two ZRTs are recommended to be connected to the HF and HFX models only.

Depending on selection, the ZRTs will be designed to operate on 120V power or 24V power provided by the ventilator itself. If you are not certain what you have, this can be easily determined by the color of the wires on the ZRTs. All ZRTs will have one green (ground) and two red (end switch) wires. The other two wires are black (120V) or yellow (24V).

ZRTs operating on 120V will require installation by a certified electrician. Low-voltage, 24V units can be installed by anyone with basic wiring knowledge. If you are not comfortable with this, please contact a local contractor for installation assistance.

Installing the Ventilator

For installation details on your ERV, please refer to page 17 Section **"Mounting the Unit."**

Installing the Zone Register Terminal to the Ventilator

VentZone® kits provided with 24V ZRTs are designed to be powered completely through the ventilator. Use of the 20/40/60 Minute Timer (P/N 611228) is recommended to prevent over ventilation and/or frost damage to the heat exchanger in cold climates.

The basic VentZone® System is designed to provide a low volume continuous rate of ventilation, with intermittent boost through the selected ZRT.


To enable the low speed mode, place a jumper between connections 1 and 3 on the terminal block as shown below.

Note: A switch can be placed on this to activate and deactivate ventilation without interfering with ZRT operation. This can be ideal for times of the year when opening a window is preferred or the home is empty for extended periods of time, i.e. disabling the ventilator for seasonal homes to lower electric costs when unoccupied.

Each ZRT will require its own timer. Connect as illustrated below.

Multi-Unit Residential ERV

VentZone® Zoned IAQ with Heat Recovery Kit



Note: the timer must be connected according to the color codes on the terminal.

Adding Accessories to the VentZone® System

Due to the operation of the VentZone® System, most ALDES controllers cannot be used.

V. MEASURING & BALANCING AIRFLOW (for EK120-HF and EK120-HR only)

Measure and Balance

The installer must measure and balance the airflow brought in from the outside and the exhaust airflow so that the difference between the two is less than 10% of the maximum airflow. This airflow balance is especially important in homes using a combustion device or in those located in areas where the ground emits radon.

If the airflows are not properly balanced, then:

- The ERV may not operate at its maximum efficiency
- A negative or positive air pressure situation may occur in the house
- The unit may not defrost properly

Excessive positive pressure may drive moist indoor air into the external walls of the building, where it may condense (in cold weather) and degrade structure components. It may also cause key holes to freeze up.

Excessive negative pressure may have several undesirable effects. In some geographic locations, soil gases such as methane and radon gas may be drawn into the home through basement/ground contact areas. Excessive negative pressure may also cause the backdrafting of vented combustion equipment.

CAREFULLY READ THE WARNINGS IN THE SECTION “PRECAUTIONS & GUIDELINES” ON PAGE 5.

Door-Port Balancing

Door-port balancing is used to determine and adjust the airflow rates of the supply and exhaust air streams by measuring the static pressure loss across the ERV core. The recommended tool for this procedure is a differential pressure gauge (with a 0.0-0.25 in. w.g. range) or a digital manometer.

Note: The airflow chart on the door of the unit is for use with the filters that come with the unit. If other filters are used, in-duct measurements of airflow may be made using pitot tube, airflow probes, or hot-wire thermal anemometer as described in later sections.


Door-Port Balancing – Measuring Airflow

1. Finish sealing the ductwork system.
2. Make sure all the ERV components are correctly installed and functioning properly.
3. Prepare the pressure gauge by mounting it according to manufacturer's instructions and zeroing the gauge.
4. Prepare the ERV and select the operating speed. For most installations, measuring at high speed permits a more accurate reading, and the system will normally remain in balance at lower speeds.
 - a. If there are dynamic elements in the duct that react to changing pressures, the ERV should be balanced at the speed it is expected to operate most of the time.
Example: If the ducting system includes zone dampers or Zoned Register Terminals (ZRT®), it must be balanced at a speed lower than normal operation. If balanced at high speed, the ERV will not be in balance at the lower speeds due to the operation of the constant airflow regulators incorporated in the ZRTs.
5. If the ERV is ducted to the forced-air HVAC system, turn that blower on high speed as well.
6. Airflows in branch lines to specific areas of the house should be adjusted first prior to balancing the unit. A smoke pencil used at the grilles is a good indicator of each branch line's relative airflow.
7. Locate the 4 ports on the door of the ERV and remove the plastic caps.
8. Refer to the drawings below and connect the tubing from the pressure gauge to the respective door ports to the outdoor air and supply air ports.

Multi-Unit Residential ERV

- 9. Record the pressure measurement.
- 10. Refer to the reference chart on the unit that shows the pressure readings versus the corresponding supply airflows. Record this airflow.
- 11. Connect the tubing to the corresponding indoor air and exhaust air door ports using the diagram above.
- 12. Repeat steps 6-8 for the exhaust airflow.
- 13. Then follow the procedure in the following section.

***Note:** Generally, the best performance of the ERV is achieved when the airflows are within 10% of each other. The airflow balance may be set for balanced airflow, slightly positive or slightly negative, depending on the particular needs of the home. Often a slight positive pressure is desired to help resist backdraft from combustion devices, radon gas, or drawing air from an attached garage.*




Balancing Airflow and Adjusting Motor Speed – FLEXControl User Interface for EK120-HR and EK120-HF

Once the airflow is measured, with the tubes still connected, turn down the higher airflow to match the lower airflow to achieve balanced airflow. This is done by adjusting the two potentiometers on the ERV, one for Supply (FAN IN) and one for Exhaust (FAN OUT).

To balance airflow, follow steps 1-5 below. To adjust the motor speed, activate the unit on HIGH SPEED by using the activation button, then follow the same steps 1-5 below.

***Note:** It is generally preferable to perform the adjustment with the unit on HIGH SPEED. The LOW SPEED is approximately 60% of the high speed. ZRT VentZone® must be balanced on LOW SPEED. See page 35.*



Detail of the potentiometers on the ERV

1. To Adjust SUPPLY (FAN IN) air stream: Connect the tubes like the diagram below shows, then turn the FAN IN potentiometer to the desired level.
2. Adjust the EXHAUST (FAN OUT) air stream: Connect the tubes like the diagram below shows, then turn the FAN OUT potentiometer to the desired level.
3. Repeat the airflow measurement and adjustment until the desired supply and exhaust airflows are obtained.
4. Remove all tubing and replace the plugs in the door ports.

Sample Door-Port Balancing Example


The static pressure reading across the fresh air is 0.19 in. w.g., indicating an airflow of 187 CFM. The reading for the stale air is 0.14 in. w.g., indicating the exhaust airflow is 170 CFM. The supply airflow should be adjusted to about 170 CFM (see section “Balancing Airflow and Adjusting Motor Speed” on page 32) until the pressure reading is about 0.17 in. w.g.

Model no :	# Série / Serial :	Date :
EK120-HRX		
Pression / Pressure	Frais / Fresh	Vicié / Stale
Pa	inH ₂ O	PCM / CFM
25.0	0.10	39
27.5	0.11	42
30.0	0.12	44
32.5	0.13	47
35.0	0.14	50
37.5	0.15	53
40.0	0.16	55
42.5	0.17	58
45.0	0.18	60
47.5	0.19	63
50.0	0.20	65
55.0	0.22	70
60.0	0.24	74
65.0	0.26	78
70.0	0.28	83
75.0	0.30	87
80.0	0.32	91
85.0	0.34	94
90.0	0.36	98
95.0	0.38	102
100.0	0.40	105
105.0	0.42	109
110.0	0.44	112
115.0	0.46	116
120.0	0.48	119
125.0	0.50	122
130.0	0.52	125
135.0	0.54	128

Note: This balancing chart is for informational use only. Do not use it to balance your unit.

IMPORTANT: Additional balancing information for EK120-HRX and EK120-HFX models

Both models are manufactured with EC constant flow motorized impellers. The constant flow function provides a “self-balancing” unit, meaning that the unit will maintain a constant flow rate over a pressure range of 0.1 to 0.8 w.g. Once the flow rate has been selected by the installer using the potentiometer, the unit will automatically maintain a constant flow rate regardless of any pressure variation in the system.



The flow rate can be increased or decreased by incrementing the speed from 1 to 4, using the CFMs shown in the following table:

Number selected using potentiometers	High speed (constant red light)	Low speed (flashing red light)
4	120 CFM	90 CFM
1	90 CFM	50 CFM

NOTE: The flow rate values shown in the table above should be used as a guide only. For more precise flow rates, connect the balancing probes and refer to the balancing steps on page 25 of this manual.

VI. MAINTENANCE

WARNING:

In order to prevent electric shock when cleaning or servicing, unplug the ERV before servicing.

Homeowners: It may be preferable to have a qualified service technician complete your ERV general maintenance.

General Maintenance



WARNING: ALWAYS UNPLUG THE DEVICE BEFORE PERFORMING MAINTENANCE

To access internal components: Remove or lift up the unit door. Remove the unit door by opening the latch and lifting the door off the hinges.

1. Air Filters
- a. With door removed or lifted up, remove the filters.

b. Follow the cleaning schedule and procedure for your unit’s filter type.

c. See the table below to determine the filter that comes standard with your unit and what replacement filter options are available from ALDES.

FILTER TYPE	
MERV 8	MERV 13
	
USE: Trap impurities	USE: Trap impurities
CARE: clean seasonally with water and detergent spray	CARE: clean seasonally with water and detergent spray

[†] High-Efficiency Equivalent

2. Recovery Core
- a. With door removed or lifted up, remove the filters. Next remove the recovery core by gently pulling it from the device. Wear gloves to protect your hands from the core’s sharp edges.

b. Follow the cleaning procedure for your unit’s core type: **Warning:** take care when opening or removing the unit’s door, in case the core was not securely installed previously and could fall out.

RECOVERY CORE TYPE
ERV
Use a damp cloth to gently clean core. Do not drench or submerge the core in water.

3. Cabinet (twice a year)
With the door removed, wipe down the inside of the cabinet with a damp cloth to remove any dust or debris.
ONLY USE WATER. DO NOT USE PRODUCTS CONTAINING SOLVENTS. DO NOT USE HOUSEHOLD CLEANING PRODUCTS.
Wipe the interior with a dry cloth.
5. Duct Work (as needed)
The ductwork running to and from the ERV may accumulate dirt.
Wipe and vacuum the ductwork once every year.
It is recommended to contact a company that specializes in duct cleaning.
6. Exterior Wall Hoods
If exterior hoods are in an accessible location, make sure they are not restricted by patio furniture, plants, snow or other obstructions. All ductwork should be cleaned every 3 years
7. Motors and fans (No maintenance needed)

After Performing Maintenance: Slide the core and filters back into the unit. Re-attach the door to its hinges and latch the handle. Plug the unit into a power source.

Replacement Filters

Part Number	Filter Type	Applicable Models	Quantity
607116	MERV 8*	All InspirAir FRESH models	1
607117	High Efficiency†	All InspirAir FRESH models	1

* Filter type is standard with unit † MERV 13 Equivalent

Technical Assistance

Canada call 1-800-262-0916

Monday-Friday, 8 a.m. to 5 p.m. Eastern Time

USA call 1-800-255-7749

Monday-Friday, 8 a.m. to 5 p.m. Eastern Time

TROUBLESHOOTING

<i>Symptom</i>	<i>Possible Causes</i>	<i>Solution</i>
The ERV does not power up (indicator light on the unit is not lit up)	<ul style="list-style-type: none"> • Unit is not plugged in • No power to outlet • Defective fuse • control board may be defective 	<ul style="list-style-type: none"> • Make sure unit is plugged in • Test outlet with another device
The ERV isn't communicating with the wall controller	<ul style="list-style-type: none"> • Wall control is set to OFF. • Terminal block is loose. • Bad low voltage connection or interruption (due to a nail in the wall, for example). 	<ul style="list-style-type: none"> • Ensure that the wall control has power (screen or LED lights illuminate). • Check wiring from to wall control for open/short circuit. • Ensure that the terminal block is well seated in the
The ERV is producing excessive vibrations	<ul style="list-style-type: none"> • Dirt on the fan wheels • Malfunctioning motor 	<ul style="list-style-type: none"> • Call contractor to perform servicing
Poor airflow	<ul style="list-style-type: none"> • Hoods or grilles are obstructed • The filters are clogged • Obstruction in the energy-recovery core • Poor power supply • Ductwork is restricting airflow to/from • Speed is set to Low • is not balanced. 	<ul style="list-style-type: none"> • Ensure that the outdoor exhaust and intake hoods are free of obstructions • Clean or replace the filters • Clean the energy-recovery core • Use wall control to increase the speed of the • Call your contractor to check supply voltage and/or balance the airflows .
Supply air feels cold	<ul style="list-style-type: none"> • Outdoor temperature is extremely cold. • Supply grille is located close to occupants • automatic defrost function is not working • Unit is in free cooling mode 	<ul style="list-style-type: none"> • Locate the supply grilles high on the walls, or in the ceiling with a diffuser. • Reduce the operating speed of the • If supply air is ducted through the furnace plenum, ensure that the and furnace fan are interlocked. • Disable free cooling (see page 24 or refer to the 611242-FC wall control user guide).

Multi-Unit Residential ERV

Indoor air is too dry (note: an ERV is not a dehumidifier, however by exchanging indoor air with outdoor air, it can reduce excess indoor humidity if the outdoor air is drier).	<ul style="list-style-type: none"> Dehumidistat wall control is set too low ERV operating speed is too high Improperly balanced ERV 	<ul style="list-style-type: none"> Increase setpoint of dehumidistat. Operate ERV at low speed. Call a contractor to balance the ERV airflows Add moisture to air with a humidifier
Indoor air is too humid and/or condensation is forming on the inside of windows	<ul style="list-style-type: none"> Dehumidistat is set too high Obstructed supply or exhaust grilles Not enough exhaust capacity near source of moisture ERV operating speed is too low 	<ul style="list-style-type: none"> Decrease the setpoint of the dehumidistat. Reduce sources of indoor humidity (steam, wet clothes, plants, firewood) and excessive temperature Operate ERV at high speed or use continuous ventilation (not intermittent or ECO modes).
Frost is forming on the ERV and/or ducts connected to the ERV	<ul style="list-style-type: none"> ERV is not balanced ERV automatic defrost function is not working Leaky vapour barrier around insulated duct Hole in flexible duct 	<ul style="list-style-type: none"> Tape and seal all joints and duct connections Repair any holes in flexible duct Call contractor to balance the ERV and verify defrost functionality
Water is accumulating in the bottom of the ERV	<ul style="list-style-type: none"> ERV is not leveled 	<ul style="list-style-type: none"> Adjust the bracket so that the ERV is leveled
ERV stays in high speed after the 20/40/60 minute timer cycle is complete	<ul style="list-style-type: none"> One or more extraction ZRT dampers remains open Timer in another bathroom is still active Dehumidistat detected excess humidity while timer was on Automatic defrost cycle is running based on cold outdoor temperature 	<ul style="list-style-type: none"> Check if wall control is set to a high speed mode (dehumidistat, high-occupancy, etc...) Check the bathroom exhaust terminals to ensure that the dampers are fully closed. Wait a maximum of 30 minutes for defrost cycle to complete.

VII. WARRANTY

What’s Included

The warranty period for residential ventilation units begins on the date of manufacture indicated on the serial number (modelYYMMXXX where YY is the year and MM the month).

The Heat Exchanger has a warranty which is dependent upon its core type:

CORE TYPE	WARRANTY
Polymeric Membrane Counter-flow ERV	Limited 5-year
ALL OTHER COVERED COMPONENTS	
Limited 5-year	

The Seller warrants to the Purchaser that any equipment manufactured by it and bearing its name plate, to be free from defects in material and workmanship, under proper and normal use and service as follows: If, at any time within the warranty of the product (see individual specifications), the Purchaser notifies the Seller that, in his opinion, the equipment is defective, and returns the equipment to the Seller’s originating factory prepaid, and the Seller’s inspection finds the equipment to be defective in material or workmanship, the Seller will promptly correct it by either, at their option, repairing any defective part or material or replacing it free of charge and return shipped lowest cost transportation prepaid (if Purchaser requests premium transportation, Purchaser will be billed for difference in transportation costs). If inspection by the Seller does not disclose any defect in material or workmanship, the Seller’s regular charges will apply. This warranty shall be effective only if use and maintenance is in accordance with our instructions and written notice of a defect is given to the Seller within such period.

This warranty is exclusive and is in lieu of any other warranties, oral or implied, specifically, without limitation, there is no warranty of merchantability or fitness for any purpose. The liability of the Seller is limited to the repair or replacement of materials or parts as set forth.

Limitation of Liability: The Seller shall not be liable for any claim or consequential or special loss or damage arising or alleged to have arisen from any delay in delivery or malfunction or failure of the equipment. The Seller’s liability for any other loss or damage arising out of or connected with the manufacture or use of the equipment sold, including damage due to negligence, shall not in any event exceed the price of the equipment supplied by Seller.

How to File a Warranty Claim

Before removing a defective product, contact ALDES for technical assistance.

If a part is proved defective, it will be replaced with another part or repaired according to the company’s assessment.

Before returning a defective product for repair, contact ALDES customer service to obtain a Return Materials Authorization (RMA). Send the defective part postage paid to the address below based on your residence. It will be returned to you postage paid.

VIII. APPENDICE

Appendix A. List of items (sold seperatly) for a standard installation.

Ceiling mount bracket for EK120 (P/N 9209-A1-09)

Digital Multifunction Controller (P/N 611242-FC) (required to enable free cooling)

Electronic humidistat with LCD (P/N 611227)

20/40/60 Minute Timer (P/N 611228)

Speed Control (P/N 611229)

Mode Control (P/N 611230)

Interior exhaust grilles

Supply diffusers Sleeves or register boxes for interior supply and exhaust

Exterior wall hoods for supply and exhaust

Insulated duct

Uninsulated duct

MR Modulo - constant airflow regulators (not recommended for constant flow models -HRX, -HFX)

NOTES

[illegible]



American ALDES Ventilation Corporation
4521 19th St. Ct. E.
Suite 104
Bradenton, FL 34203
1-800-255-7749
www.ALDES-na.com

ALDES Canada
100 Rue Carter
Saint-Leonard d'Aston, QC J0C 1M0
1-800-262-0916
www.ALDES-na.com